



DC-9

OVERHAUL/REPAIR CAPABILITY LIST



7DC-9 | Overhaul/Repair Capability

Part Number	Description
066-4013-62	NAV CDU
066-4022-02	CDU
066-422-02	NAV COMP/NAV.ACU (SIC)
131308-2	CABIN PRE-PRES CONTROL
152BL705A	INDICATOR
152BL705C	INDICATOR, EGT APU
152BL705E	E.G.T. SUPPLY
152BL705F	INDICATOR
152BL705N	INDICATOR, EXHAUST GAS TEMP
1628L709	INDICATOR,OIL TEMP
1628L709A	INDICATOR,OIL TEMP
162BL403B	INDICATOR, CSD OIL TEMPERATURE
162BL709	INDICATOR, OIL TEMP
162BL709A	INDICATOR, OIL TEMP.
1784460-656	COMPASS, INDICATOR
204012	W/S TEMP CONT.
2587335-11	VERTICAL GYRO VG311
2587788-901	SERVO
2588302-4	GYRO, DIRECTIONAL
522-0875-006	AMPLIFIER, ADDRESS
522-1836-000	RECEIVER, ADF
522-2357-017	RECEIVER, ADF
522-2450-115	RCVR 51RVI
522-2782-004	HIS INDICATOR
522-2996-000	MARKER BEACON
522-3120-005	INSTRUMENT AM
522-3875-001	HORZ SIT IND
522-3877-001	FLIGHT DIRECTOR ADI
522-4088-003	VHF RECEIVER
522-4088-009	XCVR
522-4088-203	VHF/COMM 618M-2
522-4114-003	RAD ALT INDICATOR
522-4114-006	INDICATOR, RADIO ALTIMETER
8DJ81LWT2	TACHOMETER INDICATOR
8DJ81LXF	ENGINE TACHOMETER IND
8DJ81LXF2	INDICATOR, RRM
8DJ81LXF4	INDICATOR, RRM
8DJ81LXK2	N1 TACH IND
93A152-00	CVR Control
93A152-20	CONTROLLER, CVR PANEL