



Hawker 400

OVERHAUL/REPAIR CAPABILITY LIST



Hawker 400 | Overhaul/Repair Capability

Part Number	Description
23080-005	Starter Generator
23080-064	Starter Generator
23080-series	Starter Generator
23091-002	Starter Generator
2587193-43	Directional Compass Gyro
4016341-906	Encoder
4027170-904	Horz. Ind.
501-1228-series	Power Supply
50284-003	DC Ground Fault
50284-003	D.C. Ground Fault Protection Unit
60-1321-1	Emergency Exit Light
622-0876-001	Nav. Receiver
622-1270-001	Transponder
622-1959-011	Remote Readout unit
622-2362-001	ADF Receiver
622-2363-001	ADF Antenna
622-2855-series	Rad. Alt. Transceiver
622-2898-series	Control Display
622-3710-001	ADF Antenna
622-4022-001	Radar RT
622-4160-017	Radio Alt. Ind.
622-6152-002	VHF Comm. Receiver
622-6263-series	DME Tranceiver
622-6520-series	Comm Control Head
622-6521-series	Nav. Control Head
622-6522-series	ADF Comm. Control Head
622-6523-series	ATC Control Head
622-6524-series	DME Ind.
622-7318-series	DME Ind.
7000466-902	Attitude Indicator
7000469-902	Horizontal Indicator
7001179-954	Attitude Indicator
7001182-902	Attitude Indicator
7002493-902	Horizontal Indicator
720-15900-series	Cabin Triple Indicator
93A100-80	Recorder
93A100-83	Cockpit Voice Recorder
93A151-30	Control Unit
G-9950-1	Rotating Beacon
G-9950-21	Rotating Beacon



Hawker 400 | Overhaul/Repair Capability

Part Number	Description
G-9950-36	Rotating Beacon
H341AGM1	Gyro Horizon
PC-250	Static Inverter