



# S76

## OVERHAUL/REPAIR CAPABILITY LIST



**S76 | Overhaul/Repair Capability**

<b>Part Number</b>	<b>Description</b>
066-3014-XX	ADF Indicator
066-3042-00	R.M.I.
101635-11839	Altimeter, Encoder
101720-11810	Altimeter, 3-Pointer 20K' Dual Scale
102-0059-XX	Horizon Gyro
103-0026-01	Directional Gyro
10312N01T00	T5 Indicator
10313N01R00	Triple Tach Indicator
10420N01R00	N1 Tachometer Indicator
140100-01-01	Attitude Director Ind.
155750-1	Barometric Altimeter
155751	Altimeter, Encoder
200-071-XXX	Fuel Press. Ind.
20020-XXXXXX	Airspeed Indicator 0-200 KTS
203-021-XXX	Dual Hyd. Oil Press. Ind.
203-022E11	Oil Temp./Press. Ind.
203-022-XXX	Engine Oil Press/Temp Ind.
203-023-XXX	Dual Hyd. Oil Press. Ind.
204-060-XXX	P.T.I.T. Ind.
2587193-42	Directional Gyro
303-006-XXX	Dual Torque Ind.
305-1BL	Standby Attitude Ind.
310-007-XXX	Dual Torque Ind.
313N-4D	VHF NAV Control
313N-5A	VHF Comm Control
339H-4	Radar Altimeter Ind.
34670-102	Vertical Speed Ind.
371-005-XXX	Engine Torque Press. TX
4014267-901	Radar Altimeter Ind.
4020550-904	A.D.I.
504-0033-924	Standby Attitude Ind.
520-5160-006	Course Deviation Ind.
522-3614-000	VHF Comm Control
522-3616-202	VHF NAV Control
522-3617-000	VHF Comm Control
5448-712-91-10	N1 Indicator
550-34670-102	Vertical Speed
614L-11	ADF Control
614L-13	Dual ADF Control
622-1204-XXX	Radar Altimeter Ind.



**S76 | Overhaul/Repair Capability**

<b>Part Number</b>	<b>Description</b>
622-1879-001	RCVR / TX
622-2012-011	DME Indicator
622-2506-004	R.M.I.
622-3918-001	DME Indicator
622-3920-001	DME Indicator
7000466-914	A.D.I.
7000605-XXX	Mode Selector
7000789-901	Flight Director Computer
7000839-901	Radar Altimeter Ind.
76450-00706-XXX	P.T.I.T. Indicator
76450-00801-XXX	Airspeed Indicator
76450-00901-XXX	Triple Tach Indicator
76450-00902-XXX	Dual Torque Ind.
76450-00903-XXX	N1 Tachometer Ind.
76450-00904-XXX	P.T.I.T. Ind.
76450-00906-102	Oil Temp./Press. Ind.
76450-00907-XXX	Main Xmsn Oil Press/Temp Ind.
76450-01072-XXX	Engine Oil Press/Temp Ind.
76450-01076-XXX	N1 Tachometer Ind.
76450-01078-XXX	Oil Press./Temp. Ind.
76450-01096-101	N1 Tachometer Ind.
76550-01001-103	Caution Advisory Panel
777-1493-005	ADF Control
792-6275-003	Dual ADF Control
8140BS20LW	Altimeter, Encoder
843772-103	Caution Advisory Panel
8502S20LW	Airspeed Ind.
8503S20LW	Barometric Alt.
8503S20LWMB	Barometric Alt. mb
AD-300H	A.D.I.
AD-600H	A.D.I.
AQU-6M	H.S.I.
AR-209-11	Fuel Flow Ind.
AT-206-2	Fuel Totalizer
AT-209-NL-05	Fuel Totalizer
C-14A	Directional Gyro
DDL-OC119A	Digital T5
DMYNO-05133-002	Fuel Flow Indicator
DMYNO-38704-001	Fuel Flow Indicator
DMYNO-98429-001	Clock



**S76 | Overhaul/Repair Capability**

<b>Part Number</b>	<b>Description</b>
H1901-10	N1 Tachometer Ind.
IND-41	DME Indicator
IND-41B	DME Indicator
KNI-581	R.M.I.
M3520-2	Turn & Slip Ind. 4-Min. Turn
M3637-05	Turn & Slip Ind. 4-Min. Turn
M877	Clock
MS17983-4	Stand-By Compass
MS-702	Mode Selector
PC900-1A0600PH-1*1	Fuel Flow Indicator
PC900-ECAP-0001	Fuel Flow Indicator
RA-215	Radar Altimeter Ind.
RA-315	Radar Altimeter Ind.
RC-30-VIL	V.S.I.
RCA15BK-4	Directional Gyro
RCA26BK	Horizon Gyro
RMI-36	R.M.I.
S6145-61445-1	V.S.I.
S6147-61053-101	Attitude Director Ind.
SEL-OC19XX	P.T.I.T. Indicator
SEL-OC29XX	N1 Tachometer Ind.
SEL-OC329A	Triple Tach Indicator
SETL-OC329X	Triple Tach Indicator
W33-7510-10ET-20L	Clock