



DHC-8

OVERHAUL/REPAIR CAPABILITY LIST



DHC-8 | Overhaul/Repair Capability

Part Number	Description
02R3045669	A02 Fuel Nozzle
064-1023-00	VHF COMM 1
066-1066-23	DME 1
066-1077-00	ADF 1
066-1078-04	VHF NAV 1
10013-000-02	FUEL QUANTITY MASTER INDIC
10167N01W00	FUEL QUANTITY REPEATER IN
10167N02W00	INDICATOR
10167N02W00	TORQUE PRESSURE INDICATOR
10168N01T00	TURBINE TEMP IND
10170N01R00	HIGH PRESSURE ROTOR SPEED
10171N01F01	FUEL FLOW IND
10175N01T00	TURBINE TEMP IND
10177N01R00	HIG PRESS ROTOR SPEED
21140-1134-2	INDICATOR
23088-002B	GENERATOR DC
23088-SERIES	START-GENERATORS
2587193-43	DIRECTIONAL GYRO
3034205	C01 Fuel Nozzle
3034208	B01 Fuel Nozzle
3034215	A01 Fuel Nozzle
3034219	C02 Fuel Nozzle
3034222	B02 Fuel Nozzle
3034225	A02 Fuel Nozzle
3034729	A01 Fuel Nozzle
3034731	C01 Fuel Nozzle
3034733	B01 Fuel Nozzle
3035048	C01 Fuel Nozzle
3035049	B01 Fuel Nozzle
3035056	C02 Fuel Nozzle
3035057	B02 Fuel Nozzle
3037380(A)	A02 Fuel Nozzle
3037382(A)	C01 Fuel Nozzle
3037383(A)	B01 Fuel Nozzle
3037384(A)	C02 Fuel Nozzle
3037385(A)	B02 Fuel Nozzle
3037422	B02 Fuel Nozzle
3037423	B01 Fuel Nozzle
3037425	C02 Fuel Nozzle
3037426	C01 Fuel Nozzle



DHC-8 | Overhaul/Repair Capability

Part Number	Description
3038098	C01 Fuel Nozzle
3038099	C02 Fuel Nozzle
3038103	B01 Fuel Nozzle
3038104	B02 Fuel Nozzle
3038105	B02 Fuel Nozzle
3038106	B01 Fuel Nozzle
3038108	C02 Fuel Nozzle
3038109	C01 Fuel Nozzle
3038117	A01 Fuel Nozzle
3038118	A02 Fuel Nozzle
3038699	B02 Fuel Nozzle
3038703	B01 Fuel Nozzle
3038704	C02 Fuel Nozzle
3038705	C01 Fuel Nozzle
3038706	A01 Fuel Nozzle
3038707	A02 Fuel Nozzle
3038825	A01 Fuel Nozzle
3038826	C01 Fuel Nozzle
3038827	B01 Fuel Nozzle
3039719	A01 Fuel Nozzle
3039720	C01 Fuel Nozzle
3039741	B01 Fuel Nozzle
3039742	A01 Fuel Nozzle
3039743	C01 Fuel Nozzle
3039744	B01 Fuel Nozzle
3039745	C01 Fuel Nozzle
3039746	B01 Fuel Nozzle
3039971	A02 Fuel Nozzle
3039975	A01 Fuel Nozzle
3040142	A01 Fuel Nozzle
3040143	A01 Fuel Nozzle
3040144	A01 Fuel Nozzle
3040145	A01 Fuel Nozzle
3040146	A02 Fuel Nozzle
3045307	A02 Fuel Nozzle
3045667	C02 Fuel Nozzle
3045668	B02 Fuel Nozzle
3045669	A02 Fuel Nozzle
3045670	C01 Fuel Nozzle
3045672	B01 Fuel Nozzle



DHC-8 | Overhaul/Repair Capability

Part Number	Description
3045673	A01 Fuel Nozzle
3045692	A01 Fuel Nozzle
3045776-01	B01 Fuel Nozzle
3045778-01	B02 Fuel Nozzle
3045781-01	C01 Fuel Nozzle
3045783-01	C02 Fuel Nozzle
3045786-01	A02 Fuel Nozzle
3045788-01	A01 Fuel Nozzle
31708-003A	GENERATOR
3D1472-11	DE-ICE TIMER
4016341-05	ALTIMETER
4349-150-80-10	RUDDER TRIM POSITION IND
4350-150-80-10	AILERON TRIM POSITION IND
4428-150-80-11	INDICATOR
5082-1-2	PA AMPLIFIER
5082-1-2	AMPLIFIER-PASS ADDRE
5088-1-1	UNIT-CONTROL INTERPH
51539-SERIES	GENERATOR CONTROL UNITS
522456	HYDRAULIC PRESS IND
522458	INDICATOR
522484	INDICATOR, RUDDER TRIM
522486	INDICATOR, AILERON TRIM
522778	DC POWER IND
522790	FUEL TEMP IND
522942	FLAP POSITION IND.
523188	FLAP POSITION IND
523244	FUEL TEMP IND
5347-700-80-10	DUAL LP ROTOR SPEED (NL) IND
5427-115-80-10	INDICATOR
5550-8340-N1L	TURN AND BANK IND.
60-3844-1	EMERGENCY LITES POWER SUPPLY
60-3844-3	POWER SUPPLY
622-0876-001	RADIO NAVIGATION
622-1270-XXX	ATC TRANSPONDER
622-1879-001	VHF XCVR
622-2362-XXX	ADF
622-3710-XXX	ADF ANTENNA
622-6137-XXX	VOR/ILS RCVR
622-6152-XXX	VHF/COMM XCVR
622-6153-001	VHF/COMM XCVR



DHC-8 | Overhaul/Repair Capability

Part Number	Description
622-6263-XXX	TRANSCEIVER
622-6389-001	VHF/COMM XCVR
622-6520-XXX	CONTROL VHF
622-6521-XXX	CONTROL UNIT, VOR/ILS
622-6522-XXX	CONTROL UNIT ADF
622-6523-XXX	CONTROL UNIT ATC
622-6590-001	CAD 62
622-7318-001	IND-42C
7000622-901	VERTICAL GYRO
7001179-951	INDICATOR HORIZONTAL
7001182-909	INDICATOR ATTITUDE
7002260-722	SERVO
7002260-723	SERVO
754890-2	CONROLLER TEMP.
778728-6	FAN RECIRCULATING
8047/10	ALTIMETER
8047/10DH	ALTIMETER
8047/20DH	ALTIMETER
8SC0001	START-GENERATORS
8SC0006	GENERATOR
8SC0053	FUEL QUANTITY REPEATER IN
8SC0055	TURBINE TEMP IND
8SC0065	FLAP POSITION IND
8SC0070	INDICATOR
8SC0073	DC POWER IND
8SC0085	HYDRAULIC PRESS IND
8SC0118	INDICATOR
8SC0132	BATTERY TEMP MONITOR
8SC0152	RUDDER TRIM IND
8SC0154	CONVERTER LN
8SC0158	AILERON TRIM POSITION IND
8SC0249	FUEL TEMP IND
8SC0271	FUEL TEMP IND
8SC0359	TORQUE PRESSURE INDICATOR
965-0476-088	GPWS
C-14A	DIRECTIONAL GYRO
H321ALM1	INDICATOR
SLZ9464-A1	CLIMB IND
VG-14A	VERTICAL GYRO