



SAAB 340

OVERHAUL/REPAIR CAPABILITY LIST



SAAB 340 | Overhaul/Repair Capability

| Part Number | Description |
|--------------------|-------------------------------|
| 064-1023-xx | TRANSCEIVER VHF/COM |
| 071-1210-04 | ADF CONTROL UNIT |
| 071-1215-24 | VHF COMM. CONTROL UNIT |
| 071-1234-00 | ADF ANTENNA |
| 071-1276-08 | CONTROL UNIT |
| 071-1284-04 | ADF CONTROL UNIT |
| 10010-0000-XX | FUEL QUANTITY INDICATOR |
| 10224N01R00 | GAS GENERATOR SPEED INDICATOR |
| 10227N01T00 | I.T.T. INDICATOR |
| 10251N01T00 | I.T.T. INDICATOR |
| 103680-4 | OUTFLOW VALVE |
| 103682-1 | OUTFLOW VALVE |
| 10388N01C00 | CABIN PRESSURE INDICATOR |
| 10388N02C00 | CABIN PRESSURE INDICATOR |
| 130538-1 | CTL |
| 2117966-2 | CONTROLLER |
| 30012-0000-XX | SIGNAL CONDITIONER |
| 31342-XXX | AC PWR GENERATOR |
| 3337L-B-X-X-X | RADIO MAGNETIC INDICATOR |
| 449-X | 0-5 VDC LAMP POWER SUPPLY |
| 497-0014-XXX | ATTENDANTS CRADLE |
| 497-0100-XXX | ATTENDANTS HANDSET |
| 497-0114-XXX | FLIGHT DECK CRADLE |
| 501-1478-XX | CAPSTAN |
| 51634-XXX | GENERATOR CONTROL UNIT |
| 5170-1-9 | DIGITAL REU |
| 522387 | CABIN AIR TEMP INDICATOR |
| 522396 | HYDRAULIC OIL QTY IND |
| 522406 | D C AMP/VOLT METER |
| 522781 | INDICATOR |
| 522783 | CABIN ALT/DIFF |
| 522792 | PROP RPM IND |
| 522794 | OIL PRESS TEMP ENG IND |
| 522795 | PROP OIL/TEMP IND |
| 522796 | DUAL HYDRAULIC PRESSURE IND |
| 522797 | HYDRA BRAKE PRESS |
| 522809 | BATT/FUEL TEMP IND |
| 522823 | TORQUE PRESSURE INDICATOR |
| 522834 | TRIM POS IND |
| 522858 | DUAL FLAP POSITION INDICATOR |



SAAB 340 | Overhaul/Repair Capability

| Part Number | Description |
|--------------------|----------------------------|
| 522861 | I.T.T. INDICATOR |
| 522948 | TORQUE IND |
| 523250 | HYDRA PRESS IND |
| 523267 | CONTROL BOX BLEED AIR |
| 523347 | ITT IND |
| 5934PA1 | ALTIMETER |
| 60-1321-X | POWER SUPPLY |
| 622-0876-001 | RADIO NAVIGATION |
| 622-1270-XXX | ATC TRANSPONDER |
| 622-1879-001 | VHF XCVR |
| 622-2362-XXX | ADF |
| 622-2504-XXX | WEATHER RADAR |
| 622-2855-XXX | RADIO ALTIMETER |
| 622-3975-XXX | ALTIMETER |
| 622-6137-XXX | VOR/ILS RCVR |
| 622-6152-XXX | TRANSCEIVER |
| 622-6153-001 | VHF/COMM XCVR |
| 622-6263-XXX | TRANSCEIVER DME |
| 622-6590-001 | CAD 62 |
| 622-7318-001 | IND-42C |
| 622-7337-XXX | WEATHER RADAR |
| 622-8332-001 | CAD 31 CONTROL ADAPTER |
| 622-8739-001 | ADF/ADR CONTROL CTL-62A |
| 622-8740-001 | ADF/ADR CONTROL CTL-62A |
| 64050-660-1 | AIRSPEED IND STBY |
| 64050-661-1 | AIRSPEED INDICATOR STANDBY |
| 64050-662-1 | AIRSPEED INDICATOR STANDBY |
| 64050-663-1 | AIRSPEED INDICATOR STANDBY |
| 64060-890-X | AIRSPEED IND |
| 64141-360-1 | ALTIMETER |
| 64141-361-1 | ALTIMETER |
| 64141-362-1 | ALTIMETER |
| 64141-370-1 | STBY ALTIMETER |
| 64141-372-1 | ALTIMETER |
| 7239060-XXX | CTOT Panel |
| 72FCF2050-3 | TRIM TAB ACTUATOR |
| 754661-8 | CABIN TEMP CONTROLLER |
| 8ES006794-00 | POWER SUPPLY |
| 9302342-004 | TRIM POSITION INDICATOR |
| 9302391-002 | DUAL HYD BRAKE PRESS IND |



SAAB 340 | Overhaul/Repair Capability

| Part Number | Description |
|--------------------|----------------------------|
| 9302393-001 | HYD FLUID QTY IND |
| 9302413-002 | GYRO HORIZON |
| 9302472-004 | TORQUE INDICATOR |
| 9302473-002 | PROP SPEED INDICATOR (RPM) |
| 9302478-002 | OIL PRESS TEMP INDICATOR |
| 9-441-01 | FUEL FLOW TOTALIZER |
| 9-464-XX | FUEL FLOW INDICATOR |
| 965-0476-088 | GROUND PROX WARN COMPUTER |
| 980-6001-XXX | C.V.R. |
| A-2042C | LEFT HAND PDU |
| A-2043C | RIGHT HAND PDU |
| B13-941.22.05.2.0 | AIRCRAFT CLOCK |
| BYLF51175 | SENSOR |
| BYLF51581 | SENSOR |
| D3337L-B-2-15/SB1 | RMI |
| D494-XX-001 | LANDING GEAR CONTROL |
| DL1028M61-3 | TRIM TAB ACTUATOR |
| DL3827M1-11 | TRIM TAB ACTUATOR |
| DL3827M1-17 | TRIM TAB ACTUATOR |
| DL3827M1-31 | TRIM TAB ACTUATOR |
| DL3827M1-37 | TRIM TAB ACTUATOR |
| DL3827M1-57 | TRIM TAB ACTUATOR |
| G9950-1 | NAVIGATION LIGHT |
| H341AMM1 | GYRO HORIZON |
| XW21121-256-XX-92 | WINDSHIELD CONVERTER |